

Runner Installation:

PLEASE READ



STEP 1: Make sure runner holes align on each leg of both sides.



STEP 2: If holes do not align use a rubber mallet or comparable tool to slightly move leg into position.



STEP 3: Make sure bolt is aligned straight, the threaded hole is aluminum and could be stripped if not aligned properly. Only finger tighten each bolt several turns before screwing down completely.

